



#LR-1045 / LR1050

2014 Chevrolet / GMC Roll Up Cover

STEP 1: Locate Plastic Plug in the rear inside of the stake pocket and remove.



STEP 2: Insert 1/2 of the rear clamp into the stake pocket. (clamp w/ 2 flat grips)



STEP 3: Position the longer clamp bracket w/ plastic insert and align to inner bracket. connect both using the provided bolt and washers.



STEP 4: Install the Aluminum Side Rail starting at the front using the smaller clamps provided. Slide the Side Rail into the rear clamp system. Continue Following Standard Installation Instruction Manual.

