



## Your satisfaction is important to us, please let us help!

If you have any questions or concerns during the installation, our support representatives are available to assist you.

Please call: 1-877-769-3765 or Live Chat at www.raptorseries.com

If you have damaged or missing parts please contact the company you purchased the product from and notify them of the issue right away.



CAUTION: Do not install damaged parts!!!



# Easy Return/Easy Exchange

## Want to return an item or exchange? Not satisfied with purchase?

No problem. We strongly believe in service after the sale and we stand behind our products and our service to you, our valued customer. There is no problem we can't solve for you!

Items that have been installed and/or damaged after receipt, are no longer in new and ready-to-sell condition and cannot be refunded, replaced or exchanged unless it has a manufacturer defect or was damaged in shipping. In addition, we cannot accept return on items that are not in the original packaging. Items returned in poor condition or having parts missing will not be credited.

Please note: Your request for return or replacement must be initiated within 30 days of delivery of your merchandise.

## Did your order arrive damaged?

Please do not install damaged products. Contact the company you purchased your product from as soon as possible and notify them of the damages. They will make arrangements with you to assist with the problem.

### Did you order the wrong part or receive the wrong item?

Don't worry. From time to time human error can result in problems with ordering or shipping. Contact the company you purchased your product from as soon as you notice the error. Every company has their own policy on returning parts that have been ordered incorrectly or shipped incorrectly.

In the event that you need to ship your part back to return/exchange, please ship to the warehouse below:

CYC Returns Warehouse 2415 Cathy Lane Jasper, IN 47546



# **Raptor Series Warranty**

## **LIMITED TEN (10) YEAR WARRANTY**

#### For Powder Coated Steel Products

CYC Engineering, Inc. guarantees the original purchaser of our products a limited ten (10) year warranty from the date of original purchase against manufacturer defects in materials, workmanship and finish under normal use. The step pads are covered under warranty for 1 year. This warranty does not include damage resulting from road hazards such as gravel or other debris, product misuse, improper installation, impairments from accidents, product modifications, product neglect or scratches during the life of the product. This limited ten year warranty applies only to new products and is limited to the repair or replacement of company's products. Warranty does not include costs of removal, installation, labor, inconvenience or consequential damages. Original purchaser must return defective merchandise along with the purchase receipt, to the original place of purchase.

#### LIMITED LIFETIME WARRANTY

#### For Stainless Steel Products

CYC Engineering, Inc. guarantees the original purchaser of our products a limited lifetime warranty from the date of original purchase against manufacturer defects in materials, workmanship and finish under normal use. The step pads are covered under warranty for 1 year. This warranty does not include damage resulting from road hazards such as gravel or other debris, product misuse, improper installation, impairments from accidents, product modifications, product neglect or scratches during the life of the product. This limited lifetime warranty applies only to new products and is limited to the repair or replacement of company's products. Warranty does not include costs of removal, installation, labor, inconvenience or consequential damages. Original purchaser must return defective merchandise along with the purchase receipt, to the original place of purchase.

## 5" OVAL BAR WHEEL TO WHEEL



#### Components: Hardware: Driver Side Step Bar M8 x 40MM Plastic Push Nut Hex Head Bolt Qty 1 Qty 6 Passenger Side Step Bar Qty 6 Qty 1 M12 Bolt + M10 M10 x 40MM Hex Driver Side - Rear Bracket Nut Plate Head Bolt Qty 1 Qty 6 Qty 6 Driver Side - Front & M12 Flat M10 x 30MM Center Bracket Washers **Button Head Bolts** Qty 2 Qty 6 Qty 12 Passenger Side - Front M10 Flat M12 Lock & Center Washers Washers Qty 2 Qty 6 Qty 18 Passenger Side - Rear

#### **Tools Required:**



M12 Hex

Qty 6

Head Nut

#### **Torque Specifications:**

Bracket

Rubber Gasket


Qty 1

Qty 6

For Rocker Panel Mount Installations M8 through M12 bolts and nuts are set to 15-20 ft lbs.

### Note: When installing the brackets and bars, all hardware must be left loose until all the items are attached.

- 1. Remove all contents from the package and check stainless steel tubes for any damage. Also, verify that all components and hardware listed above are included before you begin installation.
- 2. Locate factory holes in six (6) places underneath body mount.





M10 Lock


Washers


Qty 18


- **3.** Remove the **Tape** covering the factory oblong hole in the rocker panel located above the two (2) hex holes.
- **4.** Place the Plastic Push Nut onto the stud of the M12 Bolt + M10 Nut Plate (4b). Then, slide the M12 Bolt + M10 Nut Plate into the hole in the rocker panel as shown (4a).
- **5.** Front & Center Bracket Cradle face to the rear of truck and Rear Bracket Cradle truck.
- **6.** Begin installation on passenger side. Position Front Bracket, Center Bracket and Rear Bracket as shown along passenger side.











7. Line up each bracket to the 12 Bolt + M10 Nut Plate located in the rocker panel.

Fasten the Bracket onto the M12 Bolt using one (1) M12 Flat Washer, one (1) M12 Lock Washer and one (1) M12 Hex Head Nut.

Fasten the Bracket to the threaded nut using one (1) M10 Flat Washer, one (1) M10 Lock Washer and one (1) M10 x 30MM Hex Head Bolt.

If threaded inserts already exist in rocker panel holes, use (1) M8 Flat Washer, one (1) M8 Lock Washer and one (1) M8 x 40MM Hex Head Bolt.

**8.** Place the Rubber Gaskets onto each Bracket Cradle (8a.) Then, place the Step Bar onto the Brackets and fasten using two (2) M10 Flat Washers, two (2) M10 Lock Washers and two (2) M10 x 30MM Button Head Bolts (8b).


BRACKET
M12 FLAT
WASHER
M12 LOCK
WASHER
M10 FLAT
WASHER
M10 LOCK
WASHER
M10 LOCK
WASHER


STEP BAR

RUBBER

Tighten until the split lock washer is flat against bracket and snug. **DO NOT** over tighten and strip the threaded insert in the tube.

Repeat these steps for driver side installation. When all hardware is in place, everything must be tightened. See Page 1 for Torque Specifications.






## **ADDENDUM**

PINCHWELD

Dodge Ram Trucks Built After June 2015 With Driver Front Support Brace



UNDERSIDE OF BRACKET